POPSOFA.

Information before you unpack

Congratulations with your Popsofa product. Before you unpack we would like to share important information up front. You bought a Popsofa product made out of HR foam and springs which is vacuumed and pressed into a small box. Because of the compression, the product needs some time to regain its original shape. Please read the manual carefully to ensure your sofa meets your expectations.

- After unpacking, the product will return to its original state within 3 tot 7 days.
- Gently pat and press the sofa on all sides to help it expand to original size.
- Because of the compression it's possible that wrinkles appear on the fabric. You can use a garment steamer smooth the wrinkles. You can also use an iron to remove wrinkles on the sofa. Please don't use the steamer or the iron too long on the same spot because it could affect the glue which has been just to content the HR foam.

Important:

We pack your Popsofa in a super-efficient way. Because the sofa is made out of springs combined with foam it's extremely comfortable and it is possible to completely compress each element of the sofa or armchair into a small parcel without any air left in the packaging. This will benefit a lot of efficiency regarding shipping the products which will come with less negative impact on the environment.



Once your Popsofa product has been unpacked, it cannot be /!\ repacked into the original box. Please review the return policy on the website, as return shipping cost could be significant.

Time to unpack your Popsofa product!

Make sure you have enough space to unpack your Popsofa product. Be careful use when using scissors or a knife. Please only open the product by the end of the plastic packaging to avoid damaging your product.

